# UM - SJTU JOINT INSTITUTE

## Physics Laboratory I VP141

## Exercise II

#### Measurement of Fluid Viscosity

Name:

Tianyi GE

 $Student\ Number:$  516370910168

Group:

17

Instructor:

Prof. Mateusz Krzyzosiak

#### 1 Introduction

The objective of the exercise is to measure the fluid viscosity, an important property of fluids, using Stoke's method.

To analyze the free body diagram of a spherical object moving in a fluid, we find that the viscous force, the buoyancy force and the weight, where the first two forces act upwards and the last one acts downwards.

The magnitude of a drag force is related to the shape and speed of the objective as well as to the internal friction in the fluid. We use coefficient  $\eta$  to quantify the internal friction in the fluid. Hence we build a model for the drag force (viscous force) in an infinite volume of a liquid.

$$F_1 = 6\pi \eta v R$$

The magnitude of the buoyancy force is

$$F_2 = \frac{4}{3}\pi R^3 \rho_1 g,$$

where  $\rho_1$  is the density of the fluid and g is the acceleration due to gravity. The weight of the object is

$$F_3 = \frac{4}{3}\pi R^3 \rho_2 g,$$

where  $\rho_2$  is the density of the object. Since the three forces balance each other, then

$$F_1 + F_2 = F_3$$
.

Assuming that the object will be moving with constant speed  $v_t$ , we find from the equation that

$$\eta = \frac{2}{9}gR^2 \frac{\rho_2 - \rho_1}{v_t}.$$